


Instruction – Updating your Spark M-30

Step 1

Enter the update menu in the settings.




Select and enter the settings menu.

Select and enter the software update menu.

This screen should be showed by your Spark M-30.

Step 2


Connect you Spark M-30 with your computer.



Use the USB-C to USB-A cable delivered with the Spark M-30 to connect to your computer. The empty partition MTHL_UPDATE should appear.

Step 3

Copy the update bin-file to the UPDATE partition of your Spark M-30.




- Open the zip-File downloaded from www.alivion.ch, left picture. Please use files to update from our website only.
- Copy the SparkM30_vX.XX.bin (X.XX is the software version) file in the zip folder and paste it on the MTHL_UPDATE partition, the copying window should appear.
- The file should appear within one minute on the MTHL_UPDATE partition on your Spark M-30.

Step 4

- Disconnect the Spark M-30 from your computer.
- Turn the Spark M-30 off. (It doesn't matter in which menu)
- Turn the Spark M-30 on again. The device updates itself.

Step 5

Check the software version.



Select and enter the settings menu.

Select and enter the about menu.

Check if the software version corresponds to the update one. Otherwise start again at Step 1.